










mode of connection

number		code	color		
1	battery cable	A1	red	48V battery +	
2		A2	black	48V battery -	
3	motor hall cable	B1	red	motor hall sensor +	
4		B2	black	motor hall sensor -	
5		B3	blue	motor hall sensor SA	
6		B4	green	motor hall sensor SB	
7		B5	yellow	motor hall sensor SC	
8		B6	white	speed signal ss	
9	motor hall position cable	C1	blue	motor position A	individually wrapped
10		C2	green	motor position B	
11		C3	yellow	motor position C	
12	throttle cable	D1	red	throttle positive +5v	
13		D2	yellow/green	throtttle signal sp	
14		D3	black	throttle negative	
15	pas cable	E1	red	PAS +	
16		E2	black	PAS -	
17		E3	light blue	PAS signal	
18	brake cable	F1	grey	brake signal	
19		F2	black	brake negative	
20	brake cable	G1	grey	brake signal	
21		G2	blcke	brake negative	
22	display cable	H1	red/white	48V power positive	
23		H2	blue/white	lock cable	
24		H3	black/white	48V power negative	
25		H4	green /white	communication TX	
26		H5	yellow/white	communication RX	
27	light cable	I1	brown	ligh positive	
28		I2	black	light negative	
29	light cable	J1	brown	light positive	
30		I2	black	light negative	

